



Proscenium Opening - 60'
 Apron Depth - 12' (centered)
 Full Stage Width - 110'
 Apron to Back Wall - 49'

Proscenium to Grand Drape - 2' 0"
 Proscenium to 1st Leg - 3' 4"
 Proscenium to 2nd Leg - 10' 7"
 Proscenium to Midstage Traveller - 18' 6"
 Proscenium to 3rd Leg - 27' 2"
 Proscenium to Upstage Traveller - 32' 6"
 Proscenium to Cyc - 33' 2"

Doors

Doors